


Model 360



AT360 Parts List

Series No.	Part Code	Description
	AT360	
1	AT360-001	Bolt M6x10
2	AT360-002	Starter cover
3	AT360-003	Nut M18x1.5
4	AT360-004	Gasket
5	AT360-005	Starting bearing cover
6	AT360-006	shroud comp
7	AT360-007	Bolt M6x10
8	AT360-008	Flywheel
9	AT360-009	Ignition system
10	AT360-010	Bolt M6x25
11	AT360-011	Oil seal
12	AT360-012	Crankcase cover
13	AT360-013	Seal gasket
14	AT360-014	Drain plug bolt M10-1.25
15	AT360-015	governor lever
16	AT360-016	Oil seal
17	AT360-017	Gasket
18	AT360-018	clip
19	AT360-019	Nut M6
20	AT360-020	Screw M6x30
21	AT360-021	valve rocker arm
22	AT360-022	spring
23	AT360-023	carburetor spring
24	AT360-024	carburetor level comp
25	AT360-025	dowel pin
26	AT360-026	Camshaft
27	AT360-027	vale lifter
28	AT360-028	Bearing
29	AT360-029	balancing shaft
30	AT360-030	Bearing
31	AT360-031	key 4x6.5x16
32	AT360-032	Crankshaft
33	AT360-033	Bolt M8x1.25-40
34	AT360-034	connecting -rad cover
35	AT360-035	Bearing 6027

36	AT360-036	piston & connecting rod
37	AT360-037	piston pin
38	AT360-038	piston pin clip
39	AT360-039	piston
40	AT360-040	piston ring
41	AT360-041	Crankcase seal gasket
42	AT360-042	Bolt M6x8
43	AT360-043	grid board
44	AT360-044	Bolt M6x10
45	AT360-045	Oil sensor
46	AT360-046	Oil dipstick
47	AT360-047	Oil dipstick seal
48	AT360-048	Bolt M8x45
49	AT360-049	Crankcase cover
50	AT360-050	Oil seal
51	AT360-051	O-ring
52	AT360-052	Oil cap
53	AT360-053	Gasket
54	AT360-054	governor
55	AT360-055	cylinder washer
56	AT360-056	dowel pin
57	AT360-057	exhaust valve
58	AT360-058	inlet valve
59	AT360-059	cylinder head
60	AT360-060	Bolt
61	AT360-061	Bolt
62	AT360-062	Muffler flange washer
63	AT360-063	Bolt M10x1.25-70
64	AT360-064	Valve oil seal
65	AT360-065	Valve spring
66	AT360-066	Valve spring seat
67	AT360-067	Valve clip
68	AT360-068	Rocker Pin
69	AT360-069	Valve mandril
70	AT360-070	valve rocker arm
71	AT360-071	screw

72	AT360-072	pivot adjusting nut
73	AT360-073	cylinder head gasket
74	AT360-074	cylinder head shroud comp
75	AT360-075	cylinder head cover
76	AT360-076	Bolt M6x28
77	AT360-077	tube
78	AT360-078	inlet seal gasket
79	AT360-079	Carburetor mat
80	AT360-080	Carburetor
81	AT360-081	Seal gasket
82	AT360-082	Air cleaner elbow comp
83	AT360-083	Air cleaner flange
84	AT360-084	Nut M8
85	AT360-085	Bolt M6x18
86	AT360-086	Air cleaner grid
87	AT360-087	air filter element
88	AT360-088	Air cleaner cover
89	AT360-089	Bolt M6x30
90	AT360-090	Bolt M8x16
91	AT360-091	governor seat
92	AT360-092	Absorber
93	AT360-093	Fuel tank bracket
94	AT360-094	Fuel tank bracket
95	AT360-095	Engine switch and fuel alert
96	AT360-096	Bolt M6x12
97	AT360-097	Fuel tank
98	AT360-098	fuel Filter cup
99	AT360-099	Fuel tank cap
100	AT360-100	Bolt M6x25
101	AT360-101	Gasket
102	AT360-102	Spring washer
103	AT360-103	Fuel switch
104	AT360-104	Fuel pipe clip
105	AT360-105	Fuel pipe
106	AT360-106	muffler
107	AT360-107	Bolt M8x16
108	AT360-108	Nut M8
109	AT360-109	Muffler filter
110	AT360-110	Screw
111	AT360-111	Spark plug